

CNYMOD Profile Board

Directions: Cut along the border. Leave a little of the line so you can see where they line up. Match the letters, A to A, B to B, and so on. Tape the paper together so the dotted lines are exactly on top of each other. Make sure all of the other lines match up. Tape to a 1 by 6 with the bottom and one end flush to the factory cuts. Trace the outline on the board. Use a jigsaw or similar tool to cut the curved portions and a table or chop saw for the straight lines.







